

Configuration de la piscine

Dans ce menu, il s'agit d'indiquer au Quantum le branchement physique du système de chronométrage.

Sur la droite, commencez par indiquer la longueur du bassin, le nombre de couloir dans la liste ou en sélectionnant de l'une des 3 numérotations standards.

Cliquez sur les éléments de Harnais et contacts pour activer ou désactiver (croix rouge) chaque élément. La configuration doit refléter les branchements physiques que vous avez effectués.

Ci-dessous, un exemple d'une configuration standard pour une piscine de 50m de 8 couloirs avec plaques et 1 paire de chronométrage de chaque côté.

The interface is divided into two main sections: **GAUCHE** (Left) and **DROITE** (Right). At the top right, there is a checkbox labeled "Autoriser les changements" which is checked.

HARNAS (Harnesses): Each side has two slots labeled HA1 and HA2. In the GAUCHE section, HA1 is active (no red X) and HA2 is deactivated (red X). In the DROITE section, HA1 is deactivated (red X) and HA2 is active (no red X).

CONTACTS (Contacts): Each side has a set of icons representing different contact types. In the GAUCHE section, the first icon is active, and the others are deactivated. In the DROITE section, the first icon is deactivated, and the others are active.

COULOIRS (Lanes): Each side has a vertical list of 8 lanes numbered 1 to 8. Next to each lane number are icons for different types of lane markers (e.g., arrow, circle, square). In the GAUCHE section, lane 3 has an upward arrow, lane 4 has a circle, and lane 5 has a downward arrow. In the DROITE section, the same icons are present for lanes 3, 4, and 5.

GENERAL (General): Located on the right side, it includes a dropdown for "Longueur Piscine" (Pool Length) set to 50, a dropdown for "Arrivées/départs" (Arrivals/departures) set to "Arrivée à Gauche", and a dropdown for "COULOIRS" (Lanes) set to 8.

COULOIRS (Lanes): Below the GENERAL section, there are three buttons: "1-8", "0-9", and "1-10". The "1-8" button is highlighted.

DEFAUT (Default): At the bottom right, there are two buttons: "Sauvegarde" (Save) and "Relire" (Reload).

Au centre de l'écran, indiquer la numérotation des plots de départs tel que vous les voyez depuis la table de chronométrage. Y associer pour chaque ligne le numéro du harnais (numéro indiqué sur le harnais). Si l'association entre le numéro de ligne et harnais n'est pas respectée, les temps ne seront pas reçus dans les bonnes lignes.

Il peut être nécessaire de changer un numéro de harnais si par exemple un harnais est défectueux durant la compétition. Vous pouvez le remplacer par un harnais de réserve et indiquer son numéro (indiqué sur le harnais) à côté de la ligne concernée. Si les 2 côtés sont équipés de harnais, les numéros des harnais peuvent différer entre 1 côté et l'autre côté. Il suffit vraiment d'indiquer les

bons numéros de harnais installés dans cette fenêtre.

Dans le cas où votre Quantum n'est pas partagé entre plusieurs clubs, il est possible de sauvegarder la configuration par défaut pour la restaurer par la suite si besoin. La configuration est sauvegardée au sein même du logiciel Quantum.

Revision #3

Created 3 December 2023 20:53:11 by Florian

Updated 6 December 2023 20:40:18 by Florian